

To ensure that the quality of our products remain at the forefront of the industry, we are constantly striving to improve our designs and sometimes make revisions to our products. With our Alpha Macan High-Flow Air Filters, changes were made to improve install-ability and fitment.

Macan 6 Cylinder Models (Only)

01. Install included adhesive-backed foam block onto filter housing cover as shown:



02. Place filter into filter housing.

03. Slide the filter housing cover onto the filter housing until the foam block contacts the edge of the filter as shown:



- a. Compress the foam so it is able to slide over the filter
- b. Completely slide the filter housing cover over the filter housing.